


# Dual-Track System



- A-Motor /Track is in the front for the Curtain
- B- Motor /Track is behind for the Sheer
- A-Motor port-A cable goes to Wall Control.
- A-Motor port-C cable goes to B-Motor.
- Remote Control & Wall Control each has  
"A" open/close buttons  
"B" open/close buttons  
corresponding to the A-Motor and B-Motor.
- Power Adapter is always the last to plug in.
- Power Adapter is always the first to be unplug.