

## Insert or Remove Eyelets (Curtain Runners)

There is a “stopper” at each end of the track. Loosen a bit the screw and slide it out of the track.

Be noted that only turn 3 or 4 rounds of the screws is enough, there is a “nut” underneath that it should not be dropped out of the screw.

For One Way Pull, you only need to do one side of the track.

After inserting or removing the eyelets, simply put the stopper back and tighten the screw.

